



SAFETY PRECAUTIONS

WARNING

- Please ensure that children don't play with this equipment, to be operated by a qualified handler
- Ensure that the flip lock on the winch is placed in the lock position before you release the winch handle
- The winch is solely to maintain a desired height; no load should be placed during the lifting operation of the ramp section.
- Once lifted to a desirable height Ramp should be supported on the edge of the truck before a loading or unloading operation; no payload should be used without support.
- All moving parts to be checked and greased before operations.
- Safe distance to be observed during ascending and descending the ramp

Vet cattle Crush

- Crush should be operated by a qualified person
- All moving parts & slam latches on the crush should be checked before each operation. and a safe distance to be maintained during the operation process
- New bridge services pty ltd take no responsibility for any damage caused to property or persons not following safety operations of this equipment.